

Wartosc	Typ	Oznaczenie na schemacie	Ilosc
8R2	1206	R88;R90	2
10R	1206	R10;R89	2
47R	1206	R13	1
62R	1206	R1	1
82R	1206	R95	1
100R	1206	R23;R32;R41;R57;R67	5
130R	1206	R11	1
180R	1206	R21	1
300R	1206	R66	1
390R	1206	R49;R86	2
430R	1206	R80	1
470R	1206	R25;R33;R36;R52	4
510R	1206	R18;R77	2
820R	1206	R44	1
1K	1206	R16;R24;R26;R27;R40;R48;R79;	7
1K5	1206	R8	1
2K	1206	R3;R4;R9;R14;R17;R76;R81	7
2K4	1206	R7;R34;R35;R37	4
3K	1206	R20;R42;R72	3
3K9	1206	R15	1
5K1	1206	R2	1
8K2	1206	R51;R74	2
10K	1206	R5;R12;R19;R29;R30;R39;R54;R61;R82;R83;R84;R85;R87;R91;R93;R97	16
20K	1206	R56	1
22K	1206	R75;R78	2
39K	1206	R6	1
47K	1206	R22;R28;R45;R50;R55;R62;R92	7
68K	1206	R73	1
100K	1206	R96	1
200K	0805	R68;R69;R70	3
1K	0.125W	R53	1
10K	0,125W	R47	1
22K	0,125W	R43	1
39K	0,125W	R46	1
100R	PR	R94	1
1K	PR	R31	1
10K	PR	R58;R60	2
100K	PR	R65	1
200K	PR	R38	1